

Need to measure current?

Get the right tool for the job with the Martindale checklist



Whether it's low current AC, DC for PV and battery systems, or leakage current, here's the essential checklist to get the right clamp meter

- Consider minimum and maximum current levels
- Check the safety Installation Category (CAT) rating for your location
- Match the resolution and accuracy to the minimum current to be measured
- Check the jaw size for easy access and maximum conductor size.
- AC only current or AC and DC current?
- Select key features for ease of use - auto ranging, backlight and thumbwheel
- Consider additional functionality - AC/DC Voltage, Resistance and Min/Max monitoring
- Use true RMS measurement clamps & flexes for reliable and repeatable results



CM57 AC



CM69 AC Leakage
0.001mA resolution



CM79 AC/DC



CM95 Hi Res AC Flex
85mm diameter

www.martindale-electric.co.uk

Call: 01923 441717 email: sales@martindale-electric.co.uk

MARTINDALE
●●●ELECTRIC
Keeping You Safe